

Preliminary

Version 1.0
5/27/03

FireStore FS-3 Camcorder Compatibility Guide



FireStore FS-3 is designed to work with virtually any DV device. However, it is targeted at a number of full size DV, MiniDV, DVCAM and DVCPRO camcorders that features Anton/Bauer, V-Mount or NP battery systems. In these configurations, it is possible to simply mount and power FireStore FS-3 on your camcorder. A single FireWire cable connection allows for DV I/O and control.

Compatibility Information is Subject to Change

Sony DSR Series DVCAM Full Size Camcorders



Sony DSR-300A with Sony V-Mount Plate



FireStore FS-3V



IDX Endura E50



Camcorder	IDX/Sony V-Mount Plate	Anton/Bauer Plate	Req. Fire-Wire Cable	DV I/O
Sony DSR-250A	Sony or IDX PV or PV-S	-	6-6 pin	In/Out
Sony DSR-300A	Sony or IDX PV or PV-S	QR-DSR	6-6 pin	Out Only
Sony DSR-370	Sony or IDX PV or PV-S	QR-DSR	6-6 pin	Out Only
Sony DSR-500	Sony or IDX PV or PV-S	QR-DSR	6-6 pin	Out Only
Sony DSR-570	Sony or IDX PV or PV-S	QR-DSR	6-6 pin	Out Only

FS-3 Model:	
Anton/Bauer:	FS-3AB
V-Mount:	FS-3V

NOTE: Camcorders with DV Out only do not allow playback of FS-3 to camcorder.

Battery Systems
Anton/Bauer:
• Hytron 50/100
• ProPac
• DigiProPac
• TrimPac
• DigiTrimPac
• ProForma
• Dionic
Sony V-Mount:
• BPIL75
• BPL40/60/90
• BPM100/M50
IDX V-Mount:
• Endura E80/E80s
• Endura E50/E50s

Ikegami HL-DV Series DVCAM Camcorders



Camcorder	IDX/Sony V-Mount Plate	Anton/Bauer Plate	Req. Fire-Wire Cable	DV I/O
Ikegami HL-DV5	Sony or IDX PV or PV-S	OEM Supplied	6-6 pin	Out Only
Ikegami HL-DV7W	Sony or IDX PV or PV-S	OEM Supplied	6-6 pin	Out Only

FS-3 Model:	
Anton/Bauer:	FS-3AB
V-Mount:	FS-3V

NOTE: Camcorders with DV Out only do not allow playback of FS-3 to camcorder.

Battery Systems
Anton/Bauer:
• Hytron 50/100
• ProPac
• DigiProPac
• TrimPac
• DigiTrimPac
• ProForma
• Dionic
Sony V-Mount:
• BPIL75
• BPL40/60/90
• BPM100/M50
IDX V-Mount:
• Endura E80/E80s
• Endura E50/E50s

Canon XL1/XL1s MiniDV Camcorders



IDX Endura E80

FireStore FS-3V

Canon XL1s with Canon MA-100 Mount Plate and IDX A-E2XL1 Mount Plate

Camcorder	IDX V-Mount Plate	Anton/Bauer Plate	Req. Fire-Wire Cable	DV I/O
Canon XL1				
w/ MA-100/-200	A-E2XL1	QR-XL1-C	4-6 pin	In/Out
Canon XL1s				
w/ MA-100/-200	A-E2XL1	QR-XL1-C	4-6 pin	In/Out

FS-3 Model:	
Anton/Bauer:	FS-3AB
V-Mount:	FS-3V

Battery Systems
Anton/Bauer:
• Hytron 50/100
• ProPac
• DigiProPac
• TrimPac
• DigiTrimPac
• ProForma
• Dionic
Sony V-Mount:
• BPIL75
• BPL40/60/90
• BPM100/M50
IDX V-Mount:
• Endura E80/E80s
• Endura E50/E50s

Panasonic PROLINE DV & DVCPRO Camcorders

Anton/Bauer ProForma Battery



FireStore FS-3AB

Panasonic

Battery Systems

Anton/Bauer:

- Hytron 50/100
- ProPac
- DigiProPac
- TrimPac
- DigiTrimPac
- ProForma
- Dionic

Sony V-Mount:

- BPIL75
- BPL40/60/90
- BPM100/M50

IDX V-Mount:

- Endura E80/E80s
- Endura E50/E50s

FS-3 Model:

Anton/Bauer:	FS-3AB
V-Mount:	FS-3V

Camcorder	IDX/Sony V-Mount Plate	Anton/Bauer Plate	Req. Fire-Wire Cable	DV I/O
Panasonic AG-DV200	IDX PV or PV-S	OEM Supplied	6-6 pin	Out Only
Panasonic AJ-D215H	IDX PV or PV-S	OEM Supplied	6-6 pin	Out Only
Panasonic AJ-D410	IDX PV or PV-S	OEM Supplied	6-6 pin	Out Only

NOTE: Camcorders with DV Out only do not allow playback of FS-3 to camcorder.

JVC Professional DV Full Size Camcorders

Contact JVC Professional about
FireStore DR-DV5000 for JVC
Camcorders.

